

BUCKINGHAM MFG.

M2 – SERIES

(MAGNETIC STRIP RETRO FIT KIT INSTRUCTIONS)

M2-3 KIT (3" long magnetic bracket)

Kit includes:

- One 3" long magnetic bracket.
- Two ½" long 10-32 pan head screws
- Two ¾" OD washers
- Two 10-32 Nylock lock nuts



M2-8 KIT (7 7/8" long magnetic bracket)

Kit includes:

- One 7 7/8" long magnetic bracket.
- Two ½" long 10-32 pan head screws
- Four ¾" OD washers
- Two 10-32 Nylock lock nuts



The Buckingham magnetic strip is intended to be used to temporarily hold small items such as nuts, bolts, washers or hand tools and provide easy pickup with a gloved hand. It is designed

to be attached to the inside of a bag, bucket or to a tool apron. This kit may be used on products manufactured from materials such as canvas, leather or fiberglass.

MAGNETIC STRIP INSTALLATION

1. Align the magnetic strip in the desired mounting position on the board, bucket or bag.
2. Use a permanent marker and make a mark on the product at the center of each screw slot in the magnetic strip.
3. Make two holes at the marked locations. Use a sharp instrument such as a punch or an awl for canvas or leather products. Use a drill with a 7/32" bit for fiberglass products.
4. Place one washer on each screw and insert the screw through the product from the side opposite of the intended mounting location.
5. Place the magnetic strip over the two protruding screws (if using the M2-8, place an additional washer over each screw that is protruding through the magnetic strip).
6. Place a locking nut on each screw and securely tighten using a Phillips head screwdriver and a 3/8" wrench. Do not over tighten.

BUCKINGHAM MFG. CO.
BINGHAMTON, NY
www.buckinghammfg.com
1-800-937-2825